Fruits Sugar-Acid Meter (MODEL: SAM-700S)

1. BEFORE MEASUREMENT

- PLACE BATTERY 9V × 1 EA INTO BATTERY COMPARTMENT (BACK SIDE).
- (2) IF 'CAL'(SWEETNESS)/'AAA'(SOURNESS) SIGN APPEARS ON LCD, THE UNIT IS READY TO MEASURE IN NORMAL CONDITION (AUTOMATIC CALIBRATION).

2. MEASUREMENT OF SWEETNESS (BRIX %)

- (1) CLEAN 'SAMPLE WELL' WITH TISSUE AND DRIP TWO OR THREE DROPS OF TEST SOLUTION ON 'SAMPLE WELL FOR BRIX %'.
- (2) CLOSE 'SAMPLE WELL' WITH 'LIGHT COVER' AND PRESS 'MEAS.' BUTTON.
- (3) MEASUREMENT RESULT (BRIX %) APPEARS ON LCD (# AFTER 2 MINUTES. WHEN THERE IS NO OTHER OPERATION, THE POWER IS OFF-AUTO HOLD & AUTO OFF FUNCTION).
- (4) AVERAGE TEST DATA (UP TO 9 TIMES) IS AVAILABLE BY PRESSING 'AVER.' BUTTON (# IN ORDER TO SAVE BATTERY, THE UNIT TURNS OFF BY PRESSING 'AVER.' BUTTON 2 TIMES CONTINUOUSLY).

MEASUREMENT OF SOURNESS (ACID %)

1) DILUTION

- USING A SYRINGE, POUR DISTILLED WATER IN A DILUTION CONTAINER (UP TO 30ml LINE).
- (2) SQUEEZE SOME FRUITS AND PLACE FRUIT JUICE IN A CUP.
- (3) USING A PIPETTE (AFTER TIPPING), TAKE FRUIT JUICE SAMPLE (APPROX. 0.3ml) AND PUT IT INTO THE DILUTION CONTAINER.
- (4) CLOSE THE COVER OF 'DILUTION CONTAINER' AND MIX WELL FRUIT JUICE (APPROX. 0.3ml) AND DISTILLED WATER (30ml) FOR ABOUT 10 SECONDS.









2) MEASUREMENT

- (1) PLACE THE DILUTED SOLUTION ON 'SAMPLE WELL FOR ACID %' ENOUGH TO COVER IT.
- (2) PRESS 'MEAS.' BUTTON, AND MEASUREMENT RESULT (ACID %) APPEARS ON LCD.

(# WHEN TEST SOLUTION IS OUT OF MEASURING RANGE. 'ErH' SIGN APPEARS.)



MEAS, Button Sample Well

4. IMPORTANT

- (1) BEFORE EVERY MEASUREMENT, PLEASE CLEAN THE 'SAMPLE WELL'.
- (2) WHEN NO USE FOR A LONG TIME. MAKE SURE TO REMOVE THE BATTERY.
- (3) DO NOT STORE THE INSTRUMENT AT DAMP PLACE.
- (4) THE MANUFACTURER GRANTS 12 MONTHS WARRANTY PERIOD.
- (5) IN CASE OF WRONG USE OR ABUSE, WARRANTY IS NOT AVAILABLE.

G-WON HITECH CO., LTD.

WOOLIM E-BIZ, CENTER 310. #170-5, GURO-DONG, GURO-GU. SEOUL, KOREA(152-769) Tel: 82-2-2108-1646(DIR.)

Fax: 82-2-2108-1650 E-MAIL; g-won@g-won.co.kr

Other Handling Instruments

- Digital Refractometer
- Digital Salt Meter
- Flour Moisture Meter
- Wood Moisture Meter
- Grain Moisture Meter
- Coffee Bean Moisture Meter
- Seed Moisture Meter
- Tobbaco Moisture Meter



