

• AR862A+ Infrared Thermometer

- **Product No.:** AR862A+
- **Introduction:** The most basic design consists of a lens to focus the infrared (IR) energy on to a detector

- **FEATURES**

The most basic design consists of a lens to focus the infrared (IR) energy on to a detector, which converts the energy to an electrical signal that can be displayed in units of temperature after being compensated for ambient temperature variation.



SPECIFICATIONS

Measuring range : -50 to 900°C

D:S=12:1

Emissivity: 0.1 to 1.00 adjustable

°C /F Selection: ✓

Accuracy: ± 1.5% or ±1.5°C

Max/Min/Dif/Avg temperature reading: ✓

Hi-Low temperature alarm setup: ✓

12 data store/recall function: ✓

Auto power shut off : ✓

