



RED PEPPER MOISTURE METER, MODEL: GMK-310



FEATURES

- Electrical Resistance Method Adopted
- Easy to Operate and Quick Reading
- Automatic Temperature Compensation
- **Automatic Calibration**

(* The instrument has a special function of Auto-Calibration.

In spite of any changes of surrounding environment, The unit is calibrated automatically

by G-WON Hitech's preset special programs.

Once calibration is not successful, Correct test results are not possible.

By Auto-Calibration, Customers can get accurate test results easily without doing calibration before every test.)

- Large Digital LCD display

- Low Battery Sign appears
- Auto Hold & Auto Off Function Available

SPECIFICATIONS

M O D E L		GMK - 310
APPLICATION		Red Pepper
MEASURING RANGE		8.0 % ~ 27.5 %
RESOLUTION		0.1 %
MEASURING TIME		Approx. 3 Seconds
POWER SOURCE		Battery 9V × 1EA
DIMENSIONS	INSTRUMENT	85(L) × 170(W) × 36(H) mm
	SENSOR	275 mm
ACCESSORIES		Driver 1EA, Battery 9V 1EA, Carrying case 1EA, User's manual 1EA
WEIGHT		Approx. 2kg

[➤ MANUAL](#)

[➤ PRINT](#)

[☒ CLOSE](#)