# Trek Model 541 A Non-Contacting Electrostatic Voltmeter for EOS/ESD



The Trek Model 541A Electrostatic Voltmeter (pictured at left with the Model 541PR-S probe) provides accurate non-contacting measurements of the electrostatic surface voltage associated with EOS/ESD processes. The instrument is configured with a miniature electrostatic field chopper probe that can be remotely located and easily positioned within process equipment to provide highly accurate, non-contacting, DC-stable, spacing-independent voltage measurements in either ionized or non-ionized environments. A 20x4 alphanumeric LCD screen displays the present measured voltage, the positive peak voltage, the negative peak voltage and additional menu information.

## **Key Specifications**

Measurement Range	
Model 541A-1:	
Model 541A-2:	
	Model 541A-1:

• Measurement Accuracy:

Better than  $\pm 1\%$  of full scale over a probe-to-surface separation of 2.5 mm  $\pm 1$ mm

±1 kV DC or peak AC ±100 V DC or peak AC

Alphanumeric LCD Display: 20 x 4 characters

### **Typical Applications Include**

- Semiconductor
- LCD
- Electronic assembly
- ESD-sensitive processes

### **Features and Benefits**

- Chopper probe is DC-stable with or without incident air ion flow
- Drift-free measurements
- LCD screen displays present voltage and holds the most positive and negative values
- Visual and audible alarms activate when the preset voltage threshold levels are reached
- Voltage output monitor for remote monitoring or control
- USB and RS-232 serial ports
- NIST-traceable Certificate of Calibration provided with each unit
- Optional Walking Test Adapter kits available





Walking Test Adapter



Optional Walking Test Adapter kits for the Model 541A allow analysis of charge levels accumulated on the human body per compliance with ANSI/ESD STM97.2. and IEC Standard 61340-4-5. See page 2 for details.

#### Model 541A Specifications

#### Performance

Performance	
Measurement Ranges	
Model 541A-1	0 to ±1 kV DC or peak AC
Model 541A-2	0 to ±100 V DC or peak AC
Speed of Response (10% to 90%)	Less than 50 ms for a $\pm$ 1 kV step (541A-1) Less than 50 ms for a $\pm$ 100 V step (541A-2)
Accuracy	1% of full scale
Resolution	0.1%
Monitor Output	
Model 541A-1	1/100th of the measured voltage
Model 541A-2	1/10th of the measured voltage
Output Noise	Less than 30 mV rms*
Output Impedance	47 Ω
Features	
Alarms	Activated if measured voltage exceeds preset threshold limits; positive/negative limits may be programmed separately
Visual	Front-panel LEDs illuminate when thresholds are reached
Audible	ON/OFF programmable pulsating or continuous tone. (+) and (-) alarms have different tone rates for the pulsating tone selection
Alarm Relay Output	Form C relay contact with barrier strip terminals; changes state when voltage thresholds are met or exceeded
Alarm Digital Output	TTL output with a TTL low (0 to 0.8 V) as the alarm "ON" status; TTL high (2.5 to 5.0 V) indicates a normal condition
Reset Button	Resets alarms and peak hold to zero
Zero Control	Adjustable to produce zero volts when probe coupled to a known zero voltage source
Alphanumeric LCD Display	20 character by four line (20x4) LCD displays the present voltage and holds the most positive and most negative values
Ground Receptacle	Banana jack
Serial Port and USB Port	Provides control of specific functions and acquires sensor data utilizing Trek software and a PC connected to the RS-232 serial port or the USB Type B port (connectors are on back panel)
Current Output	Provides a current of 4 mA to 20 mA representing -1 kV to +1 kV (541A-1) and -100 V to +100 V (541A-2)

\*Measured using the true rms feature of the HP Model 34401A digital multimeter

**f Rek** 

dvanced

Dimensions 97 mm H x 152 mm W x 204 mm D (3.8" H x 6" W x 8" D) Weight 0.77 kg (1.7 lb.) **Operating Conditions** 15°C to 35°C (59°F to 95°F) Temperature Relative Humidity 5% to 85% RH, non-condensing Altitude To 2000 m (6561.68 ft.) Electrical Power 15 V DC ±20%, 800 mA (minimum) adapter with a 2.1 mm DC plug. Power ON/OFF Rear panel switch **Supplied Accessories** P/N 24005 Operator's Manual (with software CD) P/N F5054R Universal AC Adapter P/N N9056 6P/4C Plug Serial Cable P/N BA108 P/N N9044 Ground Cord **Optional Accessories** P/N 1K037 Walking Test Adapter - Round Body Probe P/N 1K038 Walking Test Adapter - Square Body Probe Probes Probe Miniature electrostatic field chopper probe End-view orientation Model No: 541PR-E. Aperture 1.6 mm (0.06") (round body) diameter. Dimensions 9.7 mm dia x 50 mm L 50 mm (0.38" dia. x 2" L) End View Probe Aperture 1.6 mm Model No: 541PR-S. Aperture 2.3 mm (0.09") Side-view orientation (round body) diameter. Dimensions 9.7 mm dia x 53 mm L 50 m (0.38" dia x 2.1" L) Side View Probe Aperture 2.3 mm

Select and program menu options - the ↑↓ set the alarm threshold voltages, alarm conditions

and alarm reset type

Features (cont.)

Menu ↑↓Buttons

Mechanical

Model 541P-S. Aperture 2.5 mm (0.1")

(0.22" sq x 2" L)

3 meters (9.8 ft.) nominal

2.5 mm ±1 mm (recommended)

Copyright © 2016 TREK, INC. All specifications are subject to change. 1630/

diameter. Dimensions 5.6 mm sq x 50 mm L

0 Side View Probe Aperture 2.5 mm

5.6 mm

TREK • 190 Walnut Street • Lockport, NY 14094 • USA 800-FOR TREK • 716-438-7555 • 716-201-1804 (fax) www.trekinc.com • Trek-CA@aei.com

Side-view orientation

Probe Cable Length

Separation Distance

Probe-to-Surface

(square body)

www.trekinc.com