

[SMT系列 - 貼片機 Pick and Place for small batch and prototype]

面臨少量多樣的產能、打樣板 和 自動機台無法貼特殊料件的困擾嗎? SMT系列是讓您更快能手動上件製作樣板的利器!
Encountered low volume assembly, prototyping, engineering changes, boards with high through-hole parts counts, or odd-shaped parts that can't be placed with your automatic machines!! Speed up your manual assembly department and increase your product quality with SMT-401 and SMT-402 manual assembly equipment.

SMT半自動貼片機

Semiautomatic SMT Pick and Place Machine

電壓 Power: AC 220 V 50 / 60HZ
重量 Weight: 22 KGS
氣壓 Air Source: 4 ~ 5Kg / cm²
入料器 Feeder: 16 Set
料件盒 Material Box: 90 PCS
最大可用PCB尺寸 MAX. PCB Working Size: 250 x 300mm
產能 Capacity: 20~50pcs / Minute
尺寸 Dimension: 800 x 720 x 300mm

特性:

- 特別適用樣品試作，變更頻繁少量多樣生產使用。
- 用穩定而快速吸取SMT零件貼合於PCB板上。
- X與Y滑動軸吸取SMT零件放置不會晃動。
- 360度旋轉料架，可放置90種不同零件。
- 可安裝16組SMT捲帶料架，大小料帶皆適合。
- 真空吸嘴可吸取任何大小不同SMT電子零件。
- 多台並聯，只小額投資就可達到大量生產效益。

Key Features:

- SMT-401 is great for sample design, especially for changeable small quantity diverse production.
- Suck quickly SMT components and place on the PCB.
- Sliding X and Y axils keep SMT components placed stable on PCB.
- Sucking head rotates 360 degrees. Fast changeover sucking nozzles.
- Part carousel load 90 kinds of loose components.
- Tape feeder bases hold for 16 sets of SMT tape reel
- Several SMT-401 connect to bigger production volume and increase efficiency on only small investment.



SMT半自動點膠 / 貼片機

Semiautomatic SMT Pick and Place with Dispenser

電壓 Power: AC 220 V 50 / 60HZ
重量 Weight: 22 KGS
空氣氣壓 Air Source: 4 ~ 5 Kg / cm²
入料器 Feeder: 16 Set
料件盒 Material Box: 90 PCS
最大可用PCB尺寸 MAX. PCB Working Size: 250 x 300mm
尺寸 Dimension: 800 x 720 x 300mm

SMT-402: 是一套手動的SMT貼片及點膠功能二合一產品，它包含了，自動貼片機所應有的功能，特別適合樣品試作業，及少量多樣化的生產使用。
真空取置頭: X與Y滑動軸移動非常精巧，依人體功學設計，可調整真空吸取器，自動吸取或放置，只需要以吸嘴碰觸元件，便可容易的將元件吸取，並可以360度旋轉來對位PCB。
點膠機: 內含有點膠功能，可以精準的調整出膠量，微調膠液濃度、點膠時間、膠液的流量壓力，達到精確點膠。
散料元件取置槽: 360度轉盤上有配置45個取置槽，內槽中分雙區C-MOS格，這便可存放90種不同的散料元件。
捲帶料架: 本機可同時安裝16組8mm料架。
(捲帶料架為 選購配件分三種): 8mm、12mm、16mm
PCB支撐架: 用一套L型軌道及支撐柱作為PC板的道具。

Key Features:

- SMT-402 sucks SMT components to dispense (spot glue) and place on PCB.
- Operation with step pad switch to spot glue SMT components rapidly, Easy-change pick & place nozzle
- 360° rotating head
- Fast changeovers
- Handles odd-shaped boards
- Parts carousel holds 45 loose parts in
- Built-in feeder base holds up to 12 8mm and/or 12mm tape feeders
- Tape strip feeder available for three 8mm, one 12mm, and 16mm tape feeders

