

PCE Americas Inc.
711 Commerce Way
Suite 8
Jupiter
FL-33458
USA
From outside US: +1
Tel: (561) 320-9162
Fax: (561) 320-9176
info@pce-americas.com

www.pce-instruments.com/english www.pce-instruments.com

Cable Wire Tracker 160 CB

Cable detector PCE-160 CB

Line locator for line identification / With different signal tones / Continuity test / Semi-rigid probe tip for optimum positioning / Earphone jack / Battery operated for mobile use / Sensitivity control

The PCE-160 CB line locator is a direct line locator for hard-to-reach lines. The line locator finds its application, for example in the automotive sector. When using the line locator, the transmitter is connected to the lines to be detected using the crocodile clips. The transmitter of the line locator generates a pulse signal after being turned on. With the receiver of the line locating device, the pulse signals can then be detected, for example on a cable harness. This allows a quick location of the line.

In addition to the line location, there is also the continuity test with the line locator. This feature requires only the transmitter. Also connect this directly to your wires. With the pass-through function, the operator is directly shown whether there is a closed circuit.

- Sensitivity adjustment
- Headphone jack
- Different beeps
- Cable tracking in walls and cable channels
- For mobile use
- Semi-rigid probe for optimal positioning

Specifications:

Line detection By beep

Beeps Pulsating sound, lasting sound

Further measurement function

Transmitter connection

Receiver connection

Continuity test

Alligator clips

Headphone jack

Environment operations 0 ... 50°C / 32 ... 122°F, 5 ... 95% rh

Power supply 2 x 9V block battery (incl.)

Receiver: 260 x 44 x 25 mm Probe length: 180 mm, semi-rigid

Dimensions Transmitter: $70 \times 56 \times 22 \text{ mm} / 2.8 \times 2.2 \times 0.9 \text{ in}$

Connecting cable: approx. 600 mm / 23.6 in

Receiver: approx. 202 g / < 1 lb

Transmitter: approx. 61 g / < 1 lb specifications without

Weight battery

Connection cable: approx. 600 mm / 23.6 in

Delivery scope:

- 1 x Cable detector PCE-160 CB consisting of 1 x transmitter and 1 x receiver
- 2 x 9V block batteries
- 1 x Transport bag
- 1 x User manual