

PCE Americas Inc. 711 Commerce Way Suite 8 Jupiter FL-33458 USA From outside US: +1 Tel: (561) 320-9162 Fax: (561) 320-9176 info@pce-americas.com PCE Instruments UK Ltd. Units 12/13 Southpoint Business Park Ensign way Hampshire / Southampton United Kingdom, SO31 4RF From outside UK: +44 Tel: (0) 2380 98703 9 Fax: (0) 2380 98703 9 info@pce-instruments.com

www.pce-instruments.com/english www.pce-instruments.com

Digital manometer P01-ICA

PCE-P01 Differential Pressure Manometer incl. ISO calibration certificate Portable handheld meter measures differential pressure from -0.137 to 0.137 bar (-2.000 to 2.000 psi) / Features real-time data-logging capabilities using the included PC software and USB cable

PCE-P01 is a portable handheld digital differential pressure manometer used to measure differential pressure in pneumatic, compressor and pump installations, valves, tanks and heating, ventilation and air conditioning (HVAC) systems. The PCE-P01 displays min / max / average values right on the meter's screen for comparison against current measurement values.

In addition, the PCE-P01 differential pressure manometer features real-time data-logging capabilities with an adjustable interval from 1 second to 24 hours. The device comes with $4 \times 30 \text{ cm} / 11.81$ in silicon tubes, $1 \times 9 \text{ V}$ block battery and $1 \times AC$ power adapter. Also included in the delivery contents are PC-compatible software and a USB cable. The software can be used to detect and document pressure fluctuations, and to display the data graphically or in a table. For real-time data recording, simply connect the differential manometer via USB to your computer, and save the measured values according to your selected time interval. You can then calculate average values directly in the software or export the saved data to Microsoft Excel.

- -0.137 to 0.137 bar (-2.000 to 2.000 psi) measuring range
- 11 measurement units: bar, mmHg, ozin², kgcm², psi, inH2O, kPa, ftH2O, inHg, cmH2O, mbar
- Data hold function
- Zero adjustment at any time
- Low battery indicator
- Auto power off (can be disabled)
- Large dual LCD screen with backlight (on / off mode)

- Displays min / max / average values right on the meter's screen for comparison against current measurement values

- Features real-time data-logging capabilities using the included PC software and USB cable

- Incl. ISO calibration certificate

Specifications:	
Measuring range (±)	
inH2O	55.40
psi	2.000
mbar	137.8
kPa	13.79
inHg	4.072
mmHg	103.4
ozin²	32.00
ftH2O	4.612
cmH2O	140.6
kgcm ²	0.140
bar	0.137

Resolution	
inH2O	0.01
psi	0.001
mbar	0.1
kPa	0.01
inHg	0.001
mmHg	0.1
ozin ²	0.01
ftH2O	0.001
cmH2O	0.1
kgcm ²	0.001
bar	0.001
Accuracy (at 25°C / 77°F)	$\pm 0.3\%$
Linearity	$\pm 0.2\%$
Response time	Approx. 0.5 sec.
Max. pressure	689 mbar
Operating temperature	0 50°C / 32 122°F
Storage temperature	-10 60°C / 14 140°F
Media	Air and non-explosive gases
Real-time data-logging interval	1 sec. to 24 h adjustable
Display	Dual LCD
Dimensions	210 x 75 x 50 mm / 8.27 x 2.95 x 1.97 in (H x W x D)
Weight (without batteries)	650 g / 1.44 lbs
Power supply	Battery: 1 x 9V block AC adapter: 9V DC / 500-mA

Delivery scope: 1 x PCE-P01 differential pressure manometer 4 x 30 cm / 11.81 in silicon tubes 1 x CD-ROM with PC software 1 x USB cable 1 x 9V block battery 1 x 9V DC / 500-mA power adapter 1 x Plastic carrying case 1 x User manual 1 x ISO calibration certificate