

90 / 45 Degree Flammability Tester Flame Retardant Test For Hard Casing



• Product Details:

- Place of Origin: Chian
- Brand Name: YUYANG
- Certification: CE ISO UL
- Model Number: YY138

• Payment & Shipping Terms:

- Minimum Order Quantity: 1 set
- Price: Negotiation
- Packaging Details: **Plywood Box**
- Delivery Time: 20 work days
- Payment Terms: T/T L/C Western Union
- Supply Ability: 5 sets per quarter
- Share to :

Hard Casing Flame Retardant Performance Testing Equipment with Flame Height 100mm

Products:

Hard casing retardant performance tester - Intelligent is according to the provisions of paragraph 6.10 JG3050-1998 in combustion testing requirements to develop and produce. The equipment is divide into the intelligent and common type to meet the different needs of customers; Different material thickness chooses different fire time, in order to measure the material self-extinguishing test and apply to building insulation electrical conduit and self-extinguishing test. This equipment is used to test resistance-to-fire test of single catheter which is highly accurate, automatic timing, ending the test automatically, simple and easy.

Standard:

JG 3050-1998

Features:

1. The combustion chamber with paint treatment; nice, corrosion resistance; Size: 650mm X 400mmx 1100mm

2. All sample holder made of stainless steel; corrosion resistance;

3. Import standard burner; Bunsen burner; Nozzle inner diameter is about 9mm;

4. Burner can adjust the angle of 90 °, 45 °;

5. The flame height level is about 100mm; The height of the blue flame is about 50mm

6. Automatic time recording, automatic storage; 0.1s timer accuracy;

7. PLC with touch screen control system; more intelligent test; recording test data automatically, automatic storage;

8. Imported brands pressure meter and pressure meter adjustment, the gas pressure is more stable

9. Imports needle valve, control of the flame height precisely; flame is more stable;

10. High intelligence, simple operation;

11. Automatic ignition system;

12. A flame height gauge;

13. 7 "touch screen with the programmable controller , to achieve control / testing / computing / data display.

14. Pulsed high voltage electronic automatic ignition.

15. Without holding the stopwatch ; the system automatically records the test of time,

and generates test reports;

16. The test time and fire time can be set by touch screen. Meet a variety of test standards;

17. Automatic timer device can record the test time and stored in the system; the report can be found;

Electrical:

- 1. The voltage: 220V, 50 / 60Hz;
- 2. Socket with grounding port;

Random with Annex:

- 1. Stainless steel flame height gauge
- 2. 2 pipe clamps;
- 3. Product specification;
- 4. Certificate of Approval;



5. Wooden packaging; safe and reliable transportation (freight transport);