

CV-150 Security cameras video adapter for TV Analyzers IT ALLOWS VIEWING THE CCTV CAMERA VIDEO ON THE RANGER Neo ANALYZER

- ✓ Enables displaying the pictures of CCTV cameras in the field strength meter
- ▼ TVI, AHD and CVI video formats are converted to PAL/NTSC CVBS
- ✓ Automatic detection of input video format
- ✓ Power supply from RANGER Neo analyzer

TVI, **AHD** and **CVI** are analogue video standards intended to allow HD video distribution, often referred to as **HD CCTV**, over coaxial or twisted pair cables to distances compatible with the requirements of anti-burglar and security surveillance systems.

A great majority of today's CCTV installations are done using cameras that work with any of these video formats. One of the reasons, if not the main reason, why these special video formats were created is that very often installers can reuse the existing traditional SD wiring based on RG59, RG6 or twisted pair which is definitively a plus for obvious reasons.

With the **CV-150** converter it is possible to display the video from the CCTV cameras on the screen of your **RANGER** Neo analyzer allowing you to make sure the video surveillance system in a building has been properly installed and set up even before the control room is available.

