

Wire Spark Testing Equipment Cable Testing Equipment For Rubber / Plastic Wire







Product Details:

• Place of Origin: China

Brand Name: YUYANG

Certification: GB / T3048.9 BS5099-874 AMD3110.4025

Model Number: YY604

Payment & Shipping Terms:

• Minimum Order Quantity: 1 set

Price: Negotiation

• Packaging Details: Plywood Box

• Delivery Time: 5 work days

Payment Terms: T/T L/C Western Union

Supply Ability: 8 sets per month

Share to :

BS5099-874 Cable and Wire Spark Testing Equipment, 0~30 KV Wire Test Machine

Description:

Cable and Wire Spark Testing Equipment is a synchronous weakness test instrument.let a setting voltage values loaded on insulation cyclically and the conductor

connect the ground. So there's a voltage difference between conductor and insulation to

test the quality of insulation layer.

Apply to ZBK13002-88, JB/T4728.10.93 Cable and Wire Spark Tester GB/T26873-2011

standard.

Standard:

In line with the national standard GB / T3048.9-2007 and BS5099-874, AMD3110.4025

"wire and cable insulation core DC spark test" all the requirements.

Feature:

Suitable for rubber and plastic wire and cable insulation layer quality frequency spark

test, test wire coating or insulator, the conductor for detecting the pinhole and Popi high

precision and automatic alarm and counting.

Spark test machine for the production of the finished product and seized the entire test

is to ensure that wire and cable insulation important quality test equipment.

Technical parameters:

Input voltage: AC220V 50HZ allowed to vary ± 10%

Output voltage: 0 ~ 15KV, 0 ~ 25kv, 0 ~ 30kv adjustable accuracy of ± 5%

Electrode beads: 600mm

Sensitivity <600uA / 2MA

Test voltage indication: Analog

