

Compact Ozone Meter



The Compact Ozone meter provides ozone testing using the DPD method in a waterproof, portable instrument. This instrument is ideally suited to drinking water, wastewater treatment and bottled water production.

- Long cuvette pathlength for superb resolution at low levels
- Waterproof and battery powered – ideal for field use
- Simple, language free operation; suitable for all users



Tablet reagents

Ordering Information



PTS043 Compact Ozone Meter Kit, Soft Case

Instrument, 2 cuvettes, cuvette brush, crush/stirring rods, 100 tests for ozone, instructions. Supplied in a soft case with belt loop.



PTH043 Compact Ozone Meter, Hard Case

Instrument, 4 cuvettes with lids, cuvette brush, 4 crush rods, 200 DPD No 4 Tablets, Instructions. Supplied in a hard case.



PTC043 NDF Check Standards for Ozone Meter

Neutral Density Filter Check Standards for Ozone Meter. Supplied in hard case with certification.

Technical Specification

Measuring System	Dual LED source, direct reading colorimeter
Instrument Range	0 – 3 mg/L Ozone
Display	High clarity LCD with backlight
User Interface	Blank, read, function and power keys
Data Storage	Last 10 results
Size (W x L x H) & Weight	65 x 150 x 40 mm, 200 g
Power Supply	2 x AA batteries

Test Name	Measurement Range	Part Code (250 tests)
Ozone	0 – 3 mg/L O ₃	AP056
DPD Glycine (250F)		AT056