

Technical Borescope PCE-VE 600

Wireless 4-way HD borescope for industry and craft / large 7 "LCD / 2GB memory card for photos and videos / diameter 6.0 mm / length 1 meter / 4-way optics

The Wireless 4-way HD endoscope PCE-VE 600 is an absolute optimum for maintenance technicians and development engineers. This Wireless 4-way HD endoscope allows you to have a look into the inner workings of machines and equipment and to store these images and video clips on a SD card or to transmit them directly via USB to the PC. There you can analyze it in peace or show to other people. Please, also note a small diameter of the measuring tube (6.0 mm).

This allows you to penetrate into the smallest components; and that all possible with a hose effective length of 1000 mm. With the joystick, you can move the camera tip in 4 directions. With the help of the 4-way HD endoscope (due to the flexible guidance, light weight and excellent optics) you can detect weaknesses and problem areas easily and early and thus deliberately take preventive measures so that to be compelled to perform complex dismantling first. You can also simplify your daily work and use the wireless 4-way HD endoscope PCE-VE 600 for the maintenance and inspection of your operational systems / machines; this will help to save time and costs for dismantling of the equipment.

- Wireless transmission of images to the monitor (up to 30 meters)
- 4-way probe having a 6 mm diameter and 1 meter length
- Camera IP67
- SD card for storing image and video
- Videos with voice recording
- Possibility of connection to an external monitor or PC
- Battery operation

Technical specifications

semi-flexible cable	1000 mm
cable diameter	6 mm
camera head	movable in 4 directions
display	7 "LCD (800 x 600)
optimal viewing distance	5 ... 15 cm
max. bending radius of the camera	320°
image format	.jpg (640 x 480 / 2048 x 1536)
video format	.mp4 (1920 x 1080 / 30/25 fps)
	.mp4 (1440 x 1080 / 30/25 fps)
	.mp4 (1280 x 720 / 30/25 fps)
	.mp4 (640 x 480 / 30 fps)

zoom and rotation	8x zoom / 90 ° image rotation
SD card	2 GB (max. 8GB possible)
battery	3.7v lithium battery / 1800mA
connections	AV out / USB / HDMI
selectable languages	German, English, Spanish and French
dimensions	240 x 160 x 100 mm
weight	585 g

Delivery

1 x Wireless 4-way HD endoscope PCE-VE 600 incl. joystick with 4-way optics,
1 x 2 GB SD memory card, 1 x USB cable, 1 x hook and magnet adapter, 1 x AV cable 1 x battery pack, 1 x power supply, 1 x case, operating manual

Please note: Not suitable for medical purposes!