



YASUDA
— TESTING THE LIMITS —

No.240 Tiptoe Exfoliation Tester【YASUDA SEIKI】For the tester to conduct an exfoliation test on the tiptoe of shoes

No.240 TIPTOE EXFOLIATION TESTER



JIS-S5050, BS-5131

This tester is used to conduct an exfoliation test on the tiptoe of shoes. The operator is to press the exfoliation nail to the tiptoe and read the scale when the tester is exfoliating the test specimen.

Specification

Exfoliation Jig	4 kinds
Height Adjusting Plate	T3 mm, 4.5 mm and 6 mm
Dial Gauge	Scale 9.8 N (1 kgf), Max. 490 N (50 kgf)
Dimensions/ Weight (Approx.)	W125 × D270 × H120 mm, 8 kg