Models 140ASX-140ASXT

1 or 2Ø – High Performance AC Power Source

4,000VA 15-1,200 Hz

1Ø → 0-135V_{I-N} 2Ø ··· → 0-270V

Standard Features:

- 1 phase or split phase Selectable Output from front panel or bus command.
- 15 to 1,200 Hz. Operation 5,000 Hz small signal bandwidth.
- Precision Voltage Programming 0.05% with Continuous Self-Calibration (CSC) engaged.
- True-RMS metering of volts, amps, and power.
- GPIB (IEEE-488.2) or RS-232 Interface.
- Waveform Library Arbitrary Waveform Generator.
- 99 stored programs with associated transients for static and dynamic test applications.
- UPC Studio Software Suite.
- UPC Interactive LabVIEW[™] Libraries.

Available Options:

- T versions include external transformer assembly P/N 134350 for higher voltage ranges
- Rack enclosures with caster base
- Programmable Output Impedance
- HarmonicAnalysisandWaveformSynthesis
- PeakInrushCaptureandWaveformAnalysis
- **UPC Test Manager Software Application**

UPC Manager Software Suite Master the Power of the Wave!

UPC Manager Software aives vou the tools necessary to guickly and easily operate yo AC Power Source. Wit our graphical interfac control all areas of yo AC Power Source test ing with simple prese user prompts, test sequences, test plans and custom reports.

ire.	🖗 LEC Modes - S PULLER B.		10 8
	14 · 8 8 4	🛛 · 🖗 🐣	1
	Frequency	Form	Coupling
	# HEO Spec	C Segle	P Dect
our	200	1290 W Thee	2.00:1
th	Phone 00 Valle 00	Wavefam	HI Degree
	4 E 121.00000 E	V 1- See	
ce	R (11.00000 R	V 1 See	10 13
ur	C 2 122.00000 2	V+=	20 24
t-		1000 - 1 (2000	Seene Protect
ets,	0		20.000 Augu 01 Sec
	PRECUPCIZ 4120133863 37%	a (ME (ME (WHORE)	
5			



Model 140ASX

As a member of Pacific's ASX-Series family of high performance AC Power Sources, the 140ASX offers the low acoustic noise, ease of installation, and maximum power density found in all of Pacific's high frequency, pulse width modulated AC Power Sources. Control and operational features provide a high degree of versatility and ease for applications ranging from simple, manually controlled frequency conversion to harmonic testing and sophisticated bus programmable transient simulation.

AC TEST POWER

The 140ASX is equipped with a powerful micro-controller with the ability to operate as a fully integrated test system. It supplies a variety of power conditions and transients to the device under test while metering and analyzing all output performance parameters.

FREQUENCY/ VOLTAGE CONVERSION

The 140ASX is an excellent source of stable AC Voltage over the frequency range of 15 to 1,200 Hz. The output frequency is quartz-crystal stabilized. Output voltages up to 270V, are available on the 140ASX model and up to 600V, on the 140ASXT model.

PHASE CONVERSION

With the ability to provide either single or two phase output, the 140ASX is an ideal choice to convert three-phase line voltage into precisely controlled split (twophase) or single-phase output power.

UPC SERIES CONTROLLER

Three controller models are available offering both manual and programmable control. All controllers provide manual operation from the front panel. Programmable Controllers may be operated from the front panel or from a remote interface via RS 232 or GPIB.

The Leader in AC Power Technology

An early pioneer in the development solid-state power conversion equipment, Pacific Power Source continues to develop, manufacture, and market both linear and high-performance PWM AC Power Sources. Pacific's reputation as a market and technology leader is best demonstrated by its continuing investments in both research and development and world-wide customer support. With corporate owned offices in the United States, Germany, the United Kingdom, and China, local personalized support is always available.



THE POWER OF EXPERTISE



FREOUENCY CONVERSION

AFROSPACE

R & D

MII ITARY

```
MANUFACTURING
```

140ASX-140ASXT

Output Ratings

140ASX

Rated Power (VA) ¹	Coupling Mode	Form ²	Output Voltage ³ V _{rms} Max (L-N/L-L)	Current ⁴ (A _{rms})	Frequency Range	Input Power	Unit Height In/mm/U	Unit Weight (Lbs/Kg)
4000	Direct	1Ø/2Ø	135/270	32/16	15-1200	3Ø 47-65Hz	8.75/222/5U	120 /54.5

140ASXT

Rateo	d Power (VA) ¹	Coupling Mode	Form ²	Output Voltage ³ V _{rms} Max (L-N/L-L)	Current ⁴ (A _{rms})	Frequency Range	Input Power	Unit Height In/mm/U	Unit Weight (Lbs/Kg)
	4000	Direct	1Ø/2Ø	135/270	32/16	15-1200	3Ø 47-65Hz	140ASX 8.75/222/5U	140ASX 120 /54.5
		Transformer 1.5:1	1Ø/2Ø	202/404	21.3/10.7	45-1200		Transformer Module 5.25/134/3U	Transformer Module 120 /54.5
		Transformer 2.0:1	1Ø/2Ø	270/540	16/8	45-1200			
		Transformer 2.5:1	1Ø/2Ø	338/600	12.8/6.4	45-1200			

NOTES:

1. Rated output power is based on a combination of nominal output voltage, rated current and load power factor. Values stated represent the maximum capabilities of a given model. Consult factory for assistance in determining specific unit capabilities as they might apply to your application.

2. Unit is operable as single phase with dual range capability. Output voltage range and 1/2 conversions are selected by front panel or bus commands.

3. Vmax is output voltage with nominal input and full rated load applied.

4. Available current will vary with output voltage and power factor.

ASX Power Source Specifications (PF = $1.0, V_{out} > 25\%$ F.S.)

Output Frequency	Line Regulation	Load Regulation (Direct coupled)	Output Distortion	Ripple and Noise	Response Time
Full Power 15-1,200Hz Direct Coupled 45-1,200 Hz Transformer Coupled	0.1% max for a ±10% line change	0.25% 15 to 400 Hz., 0.50% 400 to 1,200 Hz. Transformed Coupled 2 to 5% depending on ratio Improves to <0.1% with external sense and CSC enabled.	0.25% THD _{AVG} 15 to 200 Hz 1.25% THD _{AVG} 200 to 1,200 Hz	-66dB	60 msec typ. 10-90% load step

Input Power Requirements (47-63 Hz)

Input Voltage	208V 3Ø∆ ±10%	220V 3Ø∆ ±10%	240V 3Ø∆ ±10%	220/380V 3Ø ±10%	230/400V 3Ø ±10%	240/416V 3Ø ±10%	277/480V 3Ø ±10%
Input Current	13A _{rms}	12A _{rms}	11A _{rms}	7A _{rms}	7A _{rms}	6.5A _{rms}	Cost Option
Recommended Input Service	20A	20A	15A	10A	10A	10A	Contact Factory


* Power Source equipped with soft start feature. In-rush current at application of input power will not exceed recommended input service.

Power Factor Rating Curves

Rated Continuous load current as a function of Power Factor and Output Voltage-Nominal Input Line



Short term overload s to 40A are permitted. Operating time before thermal shutdown or circuit breaker trip varies from seconds to severa; minutes depending upon line and tempertature conditions.



Short term overload s to 20A are permitted. Operating time before thermal shutdown or circuit breaker trip varies from seconds to severa; minutes depending upon line and tempertature conditions.

140ASX-140ASXT

Total Control, Metering, and Analysis of AC Power - Simple, Intuitive Operation

The UPC Controller is a highly versatile one, two, or three phase oscillator/signal generator designed to control any of Pacific's AC Power Sources. Three controller models, UPC-1M, UPC-1, or UPC-12 are offered for use with the 140ASX.

Using the front panel keyboard and display, all controller models provide for selection of power source output mode, coupling, voltage, and frequency. Selecting the correct UPC controller for a given application varies with your test requirement, desired features, and price.

Both the UPC-1 and UPC-12 Controllers are available with either RS-232 or GPIB remote interface. Commands are structured in accordance with SCPI (Standard Commands for Programmable Instruments).


	Controller	Models	
Features	UPC-1M	UPC-1	UPC-12
Output Modes	1Ø &2Ø	1Ø & 2Ø	1Ø, & 2Ø
Waveform Library	Sine	Sine + 21 Editable	Sine + 15 Editable
Transient Functions	NO	YES, 50 Steps	YES, 99 Steps
Program Library	NO	99 Programs	99 Programs
Programmable Current Limit	YES	YES	YES
Programmable Current Protect	YES	YES	YES
CSC (Continuous Self-Calibration)	YES	YES	YES
Remote Interface Std Opt	NONE NONE	RS-232 GPIB	GPIB RS-232
Waveform Synthesis/Analysis	NO	OPTIONAL	OPTIONAL
Prog. Output Impedance	NO	OPTIONAL	OPTIONAL
Inrush Peak Detect	NO	OPTIONAL	NO
DRM Link-Synchronization	NO	NO	OPTIONAL
Line Synchronization	NO	NO	OPTIONAL

External Inputs/Outputs

Analog Auxilary Input	Each phase is algebraically summed with UPC waveform and amplified 25X to the direct coupled output. ± 10 Vpk (20Vpk-pk). One input per phase, $Z_{\rm IN} = 600 \ \Omega$
AM-Amplitude Modulation	± 10 Vdc (20Vpk-pk) modulates the output voltage $\pm 100\%$ One input per phase. Z_{\rm N} = 600 \Omega
Sync Outputs Zero Crossing	Positive Zero Crossing (0°) of Phase A analog output
Transient Trigger	Pulse at the start of a transient event. (UPC-12 only)
Transient Pedestal	TTL True when a transient is in progress
Output Clock	UPC-1, TTL level pulse rate varies with output frequency

Waveform Control

Waveform Synthesis (/HAS Option)	Creates waveform by entering magnitude as % of fundamental and specified phase angle for 2nd through the 51st harmonic	
Waveform Analysis (/HAS Option)	Reports waveform harmonic content and phase angle relative to the fundamental for the 2nd through the 51st harmonic as Total, Odd, and Even harmonic distortion	



Output Control Specifications

	l	JPC-1M/UPC-1	UPC-12			
Frequency	Range	15-1,200Hz	20-5,000Hz ⁽¹⁾			
	Resolution	Resolution 4 Significant Digits				
	Accuracy	Accuracy ±0.01% of full scale				
Voltage	Range (l-n)	Range (l-n) 0 - 150/375				
	Resolution	Resolution 0.1V/ 0.5V				
	Accuracy 0.5% of full scale (CSC Disabled) ±0.05% referenced to Internal Meter (CSC Enabled)					
Phase Angle	Range 0-359°					
ØB and ØC relative to ØA	Resolution ±1°					
	Accuracy	15.00 - 150Hz, ± 0.5° 15.00 - 300 Hz, ± 1° 15.00 - 600 Hz, ± 2° 15.00 - 1,200Hz, ± 3°	±0.5°			
Current Limit	Range	1Ø=0-300 Apk	3Ø = 0 - 100 Apk			
	Resolution	0.05	5% F.S.			
	Accuracy	±3% F.S.	±1% F.S.			
	(1) E. II					


(1) Full power output limited to 1,200 Hz in ASX models

Output Metering

	ι	JPC-1M/UPC-1	UPC-12		
Voltmeter	Range	Range 0-354 VL-N, 708VL-L			
True V _{rms} each phase	Resolution	0.1 Vrms front panel, 0.0	01 Vrms via remote interface		
1	Accuracy	±0.2% F.S plus Cal ref.	50-500Hz, ± 0.25% or rdg. ± 0.1% F.S. 20-5,000 Hz, ± 0.5% F.S.		
Ammeter	Range	1Ø = 120 Apk, 2	Ø=60Apk		
True A _{rms} and Apk each phase	Resolution	0.01 Arms or peak front interface	panel, 0.001 Arms via remote		
	Accuracy	±0.2% F.S plus Cal ref.	±0.25% of rdg. 50-500Hz, ± 0.1% F.S. 20-5,000 Hz, ± 0.5% F.S.		
Power Meter True Watts and Volt-Amps each phase	Range 42,480 (W or VA)				
	Resolution 1.0 Watt or VA to front panel, 0.001] I or] VA via remote interface				
	Accuracy	±1% full range	±0.25% of rdg. plus 50-500Hz, ± 0.1% F.S. 20-5,000 Hz, ± 0.5% F.S.		
Power Factor	Resolution		displayed to three the decimal point.		
Ratio: kW _{mtr} /kVA _{mtr}	Accuracy				
Crest Factor Ratio: Apk/Arms	Resolution		displayed to three the decimal point.		
nutio. Apit/ mis	Accuracy	± 1 % ful	l range		
Freq. Display	Range	15.00 -1,200 Hz	20.00-5,000Hz		
	Resolution	100.0-999	99 Hz, 0.01 Hz 1.9 Hz, 0.1 Hz 30 Hz, 1 Hz		
	Accuracy	± 0.01%	full range		



140ASX-140ASXT



140ASXT-UPC1 Power Source shown with external high range magnetics module.

General/Environmental

Temperature:	Operating: 0° to 55° C Storage: -10 ° to 70° C
Humidity:	0 - 95%, Non-condensing
Cooling:	Front and side forced air intake (300 CFM) with rear exhaust. Automatic Fan Speed Control for low acoustic noise and extended fan life.
Altitude:	Operating: 6,500 Ft (1,981m) Storage: 40,000 Ft (12,192 m)
Heat Dissipation:	2kBTU/ hr (Full kW Load)
Audible Noise:	Variable speed fans 65 dba Max @ 1 Meter
Agency Approvals:	Safety UL 61010 -1 EN 61010 -1 EMC EN 61326 -1

Protection and Safety

Hardware	Over-current, short circuit, over- temperature
Programmable Current Limit	A single RMS programmed, average responding, value provided for all phases. Limits current by reducing output voltage.
Programmable Current Protect	Allows the power source to operate in "constant voltage" mode, interrupting output when specified current protect limit is exceeded.

Mechanical Specifications

Height	140ASX: 5U (8.75", 222mm) Transformer Module: 3U (5.25", 133mm)
Depth	140ASX: 23.12" (587mm) Transformer Module: 23.5 (597mm) (Approx. from front panel to the rear of chassis).
Weight	140ASX - 120 lbs (54.5kg) Transformer Module: 120 lbs (54.5 kg)
Mounting	Standard 19" rack (483mm). Cabinet options available.


Hardware Options

/M7073	Safety Interlock Normally Open Contacts
/M99413	Safety Interlock Normally Closed Contacts
/P000828	15U rack enclosure, heavy duty vertical cabinet with casters and rear screen. Ordered as separate line item.
/MXXXXX	Other factory specified modification

Software/Firmware Options

/S	RS-232 Interface, 38.4 KBps (std UPC-1)
/G	GPIB Interface, IEEE-488.2, (std UPC-12)
/Prog-z	Programmable Output Impedance (not available with UPCxM)
/HAS	Harmonic Analysis and Synthesis (not available with UPCxM)
/IR	In-Rush Meter. Capture and view peak in-rush current values via front panel or remote interface (UPC-3 only).
Test MGR	UPC Test Manager License: Create, edit, and execute Test sequences and reports. Ordered as separate line item.
Test SEQ	Avionics test sequences; DO-160, ABD-0100, ABD-0100 (A350), Ordered as separate line item. Requires 'Test' Manager License.

Ordering Information



Order Example

140ASXT-UPC1/G, T= 2.0:1, V_{IN}: 220/380VAC

- 4 kVA, 1-Phase, AC Power Source with optional transformer assembly and UPC-1 programmable controller.
- Optional GPIB Interface
- 2.0:1 Transformer Ratio
- 220/380V, 3 Phase Input Voltage

Typical Delivery Items

- AC Power Source
- English Manuals (AC Source and Controller)
- UPC Studio Software (Download)
- UPC Interactive LabVIEWTM Libraries (Download)
- Compliance Certificate with Test data
- CE Conformity Document (CE Models)

Available Models

With Manual Controller

140ASX-UPC1M 140ASXT-UPC1M

With Programmable Controller

140ASX-UPC1 140ASXT-UPC1

140ASX-UPC12 140ASXT-UPC12



17692 Fitch, Irvine, CA 92614 USA Phone: +1 949.251.1800 Fax: +1 949.756.0756 Toll Free: 800.854.2433 E-mail: sales@pacificpower.com www.pacificpower.com

© 2013 Pacific Power Source, Inc. Subject to change without notice. #DS140ASX0917