1 or 2Ø – High Performance AC Power Source

2,000VA 15-1,200 Hz

1Ø → 0-150V_{L-N} 2Ø → 0-300V_{I-I}



Standard Features:

- 1 phase or split phase Selectable Output from front panel or bus command.
- 15 to 1,200 Hz. Operation 5,000 Hz small signal bandwidth.
- Precision Voltage Programming 0.05% with Continuous Self-Calibration (CSC) engaged.
- True-RMS metering of volts, amps, and power.
- GPIB (IEEE-488.2) or RS-232 Interface.
- Waveform Library Arbitrary Waveform Generator.
- 99 stored programs with associated transients for static and dynamic test applications.
- UPC Studio Software Suite.
- UPC Interactive LabVIEW[™] Libraries.

Available Options:

- Rack enclosures with caster base
- Programmable Output Impedance
- HarmonicAnalysisandWaveformSynthesis
- $\bullet \quad \text{PeakInrush Capture and Waveform Analysis} \\$
- UPC Test Manager Software Application

UPC Manager Software Suite Master the Power of the Wave!

UPC Manager Software gives you the tools necessary to quickly and easily operate your AC Power Source. With our graphical interface control all areas of your AC Power Source testing with simple presets, user prompts, test sequences, test plans and custom reports.



Model 120ASX

As a member of Pacific's ASX-Series family of high performance AC Power Sources, the 120ASX offers the low acoustic noise, ease of installation, and maximum power density found in all of Pacific's high frequency, pulse width modulated AC Power Sources. Control and operational features provide a high degree of versatility and ease for applications ranging from simple, manually controlled frequency conversion to harmonic testing and sophisticated bus programmable transient simulation.

ACTEST POWER

The 120ASX is equipped with a powerful micro-controller with the ability to operate as a fully integrated test system. It supplies a variety of power conditions and transients to the device under test while metering and analyzing all output performance parameters.

FREQUENCY/VOLTAGE CONVERSION

The 120ASX is an excellent source of stable AC Voltage over the frequency range of 15 to 1,200 Hz. The output frequency is quartz-crystal stabilized. Output voltages up to 300VL-L are available on the 120ASX model.

UPC SERIES CONTROLLER

Three controller models are available offering both manual and programmable control. All controllers provide manual operation from the front panel.

Programmable Controllers may be operated from the front panel or from a remote interface via RS 232 or GPIB.

The Leader in AC Power Technology

An early pioneer in the development solid-state power conversion equipment, Pacific Power Source continues to develop, manufacture, and market both linear and high-performance PWM AC Power Sources. Pacific's reputation as a market and technology leader is best demonstrated by its continuing investments in both research and development and world-wide customer support. With corporate owned offices in the United States, Germany, the United Kingdom, and China, local personalized support is always available.







Output Ratings

120ASX

Rated Power (VA) ¹	Coupling Mode	Form ²	Output Voltage ³ V _{rms} Max (L-N/L-L)	Current ⁴ (A _{rms})	Frequency Range	Input Power	Unit Height In/mm/U	Unit Weight (Lbs/Kg)
2000	Direct	1Ø/2Ø	150/300	20/14	15-1200	1Ø	5.25/133/3U	75 Lbs/34Kgs

NOTES:

- 1. Rated output power is based on a combination of nominal output voltage, rated current and load power factor. Values stated represent the maximum capabilities of a given model. Consult factory for assistance in determining specific unit capabilities as they might apply to your application.
- 2. Unit is operable as single phase with dual range capability. Output voltage range and 1/2 conversions are selected by front panel or bus commands.
- 3. Vmax is output voltage with nominal input and full rated load applied.
- 4. Available current will vary with output voltage and power factor.
- 5. Source rated at 3kVA in 2Ø mode.

ASX Power Source Specifications (PF = 1.0, $V_{out} > 25\%$ F.S.)


Output Frequency	Line Regulation	Load Regulation (Direct coupled)	Output Distortion	Ripple and Noise	Response Time
Full Power 15-1,200Hz Direct Coupled	0.1% max for a ±10% line change	0.25% 15 to 400 Hz., 0.50% 400 to 1,200 Hz. Improves to <0.1% with external sense and CSC enabled .	0.25% THD _{AVG} 15 to 200 Hz 1.25% THD _{AVG} 200 to 1,200 Hz	-66dB	60 msec typ. 10-90% load step

Input Power Requirements (47-63 Hz)

Input Voltage	100VAC ±10%	110VAC ±10%	120VAC ±10%	208VAC ±10%	210VAC ±10%	220VAC ±10%	230V ±10%	240V ±10%
Input Current	22A _{rms}	20A _{rms}	18A _{rms}	10A _{rms}	10A _{rms}	10A _{rms}	9A _{rms}	9A _{rms}
Recommended Input Service	25A	25A	25A	15A	15A	15A	15A	15A


Power Factor Rating Curves

Rated Continuous load current as a function of Power Factor and Output Voltage-Nominal Input Line





Short term overloads to 30A are permitted. Operating time before thermal shutdown or circuit breaker trip varies from seconds to several minutes depending upon line and temperature conditions.



OUTPUT VOLTAGE-AC VOLTS RMS

Short term overloads to 15A are permitted. Operating time before thermal shutdown or circuit breaker trip varies from seconds to several minutes depending upon line and temperature conditions.



Total Control, Metering, and Analysis of AC Power - Simple, Intuitive Operation

The UPC Controller is a highly versatile one, two, or three phase oscillator/signal generator designed to control any of Pacific's AC Power Sources. Three controller models, UPC-1M, UPC-1, or UPC-12 are offered for use with the 120ASX.

Using the front panel keyboard and display, all controller models provide for selection of power source output mode, coupling, voltage, and frequency. Selecting the correct UPC controller for a given application varies with your test requirement, desired features, and price.

Both the UPC-1 and UPC-12 Controllers are available with either RS-232 or GPIB remote interface. Commands are structured in accordance with SCPI (Standard Commands for Programmable Instruments).

Controller Models


Features	UPC-1M	UPC-1	UPC-12
Output Modes	1Ø &2Ø	1Ø & 2Ø	1Ø, & 2Ø
Waveform Library	Sine	Sine + 21 Editable	Sine + 15 Editable
Transient Functions	NO	YES, 50 Steps	YES, 99 Steps
Program Library	NO	99 Programs	99 Programs
Programmable Current Limit	YES	YES	YES
Programmable Current Protect	YES	YES	YES
CSC (Continuous Self-Calibration)	YES	YES	YES
Remote Interface Std Opt	NONE NONE	RS-232 GPIB	GPIB RS-232
Waveform Synthesis/Analysis	NO	OPTIONAL	OPTIONAL
Prog. Output Impedance	NO	OPTIONAL	OPTIONAL
Inrush Peak Detect	NO	OPTIONAL	NO
DRM Link-Synchronization	NO	NO	OPTIONAL
Line Synchronization	NO	NO	OPTIONAL

External Inputs/Outputs

Analog Auxilary Input	Each phase is algebraically summed with UPC waveform and amplified 25X to the direct coupled output. ± 10 Vpk (20Vpk-pk). One input per phase $Z_{\text{IN}}=600~\Omega$
AM-Amplitude Modulation	± 10 Vdc (20Vpk-pk) modulates the output voltage $\pm 100\%$ One input per phase. Z $_{\rm I\!N}$ = 600 Ω
Sync Outputs Zero Crossing	Positive Zero Crossing (0°) of Phase A analog output
Transient Trigger	Pulse at the start of a transient event. (UPC-12 only)
Transient Pedestal	TTL True when a transient is in progress
Output Clock	UPC-1, TTL level pulse rate varies with output frequency UPC-12, TTL level 1024 x output frequency

Waveform Control

	Wavelolli Collilloi
Waveform Synthesis (/HAS Option)	Creates waveform by entering magnitude as % of fundamental and specified phase angle for 2nd through the 51st harmonic
Waveform Analysis (/HAS Option)	Reports waveform harmonic content and phase angle relative to the fundamental for the 2nd through the 51st harmonic as Total, Odd, and Even harmonic distortion



Output Control Specifications

	output control specifications				
	ı	UPC-1M/UPC-1	UPC-12		
Frequency	Range	15-1,200Hz	20-5,000Hz ⁽¹⁾		
	Resolution	4 Signifi	cant Digits		
	Accuracy	Accuracy ±0.01% of full scale			
Voltage	Range (I-n)	0 - 1	50/375		
	Resolution	Resolution 0.1V/ 0.5V			
	Accuracy 0.5% of full scale (CSC Disabled) ±0.05% referenced to Internal Meter (CSC Enabled)				
Phase Angle	Range 0-359°				
ØB and ØC relative to ØA	Resolution	±	1°		
	Accuracy	15.00 - 150Hz, ± 0.5° 15.00 - 300 Hz, ± 1° 15.00 - 600 Hz, ± 2° 15.00 - 1,200Hz, ± 3°	±0.5°		
Current Limit	Range	1Ø=0-300 Apk	3Ø = 0 - 100 Apk		
	Resolution	0.05	5% F.S.		
	Accuracy	±3% F.S.	±1% F.S.		

(1) Full power output limited to 1,200 Hz in ASX models

Output Metering

	Outpu	it wietering		
	l	JPC-1M/UPC-1	UPC-12	
Voltmeter	Range 0-354 VL-N, 708 VL-L			
True V _{rms} each phase	Resolution	0.1 Vrms front panel, 0.0	01 Vrms via remote interface	
	Accuracy	±0.2% F.S plus Cal ref.	50-500Hz, ± 0.25% or rdg. ± 0.1% F.S. 20-5,000 Hz, ± 0.5% F.S.	
Ammeter	Range	1Ø = 120 Apk, 2	Ø = 60Apk	
True A rms and Apk each phase	Resolution 0.01 Arms or peak front panel, 0.001 Arms via remote interface			
	Accuracy	±0.2% F.S plus Cal ref.	$\pm 0.25\%$ of rdg. 50-500Hz, $\pm 0.1\%$ F.S. 20-5,000 Hz, $\pm 0.5\%$ F.S.	
Power Meter	Range 42,480 (W or VA)			
True Watts and Volt-Amps each	Resolution 1.0 Watt or VA to front panel, 0.001 kW or kVA via remote interface			
phase	Accuracy	±1% full range	±0.25% of rdg. plus 50-500Hz, ± 0.1% F.S. 20-5,000 Hz, ± 0.5% F.S.	
Power Factor	Resolution	lution Calculated and displayed to three digits following the decimal point.		
Ratio: kW _{mtr} /kVA _{mtr}	Accuracy	racy ± 1 % full range		
Crest Factor Ratio: Apk/Arms	Resolution	Calculated and displayed to three digits following the decimal point.		
	Accuracy	± 1 % full	l range	
Freq. Display	Range	15.00 -1,200 Hz	20.00-5,000Hz	
	Resolution 10.00-99.99 Hz, 0.01 Hz 100.0-999.9 Hz, 0.1 Hz 1,000-5,000 Hz, 1 Hz			
	Accuracy \pm 0.01% full range			



120 ASX-UPC1 Power Source





General/Environmental

Temperature:	Operating: 0° to 55° C Storage: -10° to 70° C
Humidity:	0 - 95%, Non-condensing
Cooling:	Side forced air intake (300 CFM) with rear exhaust. Automatic Fan Speed Control for low acoustic noise and extended fan life.
Altitude:	Operating: 6,500 Ft (1,981m) Storage: 40,000 Ft (12,192 m)
Heat Dissipation:	1k BTU/ hr (Full kW Load)
Audible Noise:	Variable speed fans 65 dba Max @ 1 Meter
Agency Approvals:	Safety UL 61010 -1 EN 61010 -1 EMC EN 61326 -1

Protection and Safety

	Protection and Salety		
Hardware	Over-current, short circuit, over-temperature		
Programmable Current Limit	A single RMS programmed, average responding, value provided for all phases. Limits current by reducing output voltage.		
Programmable Current Protect	Allows the power source to operate in "constant voltage" mode, interrupting output when specified current protect limit is exceeded.		

Mechanical Specifications

	Height	120ASX: 3U (5.25, 133mm)
	Depth	120ASX: 23" (584mm)
	Weight	120ASX: 80 lbs (36kg)
	Mounting	Standard 19" rack (483mm). Cabinet options available.

Hardware Options

/M7073	Safety Interlock Normally Open Contacts
/M99413	Safety Interlock Normally Closed Contacts
/M99526	Input Current Soft Start Option
/MXXXXX	Other factory specified modification

Software/Firmware Options

/S	RS-232 Interface, 38.4 KBps (std UPC-1)	
/G	GPIB Interface, IEEE-488.2, (std UPC-12)	
/Prog-z	Programmable Output Impedance (not available with UPCxM)	
/HAS	$Harmonic\ Analysis\ and\ Synthesis\ (not\ available\ with\ UPCxM)$	
/IR	In-Rush Meter. Capture and view peak in-rush current values via front panel or remote interface (UPC-3 only).	
Test MGR	UPC Test Manager License: Create, edit, and execute Test sequences and reports. Ordered as separate line item.	
Test SEQ	Avionics test sequences; DO-160, ABD-0100, ABD-0100 (A350), Ordered as separate line item, Requires 'Test' Manager License.	

Ordering Information

Model	Controller	Options	Input Voltage (V _{IN})
☐ 120ASX	UPC1M UPC1 UPC12	See List Above	100 VAC ±10%, 47-63Hz 110 VAC ±10%, 47-63Hz 120 VAC ±10%, 47-63Hz 200 VAC ±10%, 47-63Hz 208 VAC ±10%, 47-63Hz 220 VAC ±10%, 47-63Hz 230 VAC ±10%, 47-63Hz 240 VAC ±10%, 47-63Hz

120ASX-UPC1/G, V_{IN}: 230VAC

Order Example

- 2 kVA, 1-Phase, AC Power Source with optional transformer assembly and UPC-1 programmable controller.
- Optional GPIB Interface
- 2.0:1 Transformer Ratio
- 230 VAC, 2 Phase Input Voltage

Typical Delivery Items

- **AC Power Source**
- English Manuals (AC Source and Controller)
- UPC Studio Software (Download)
- UPC Interactive LabVIEWTM Libraries (Download)
- Compliance Certificate with Test data
- CE Conformity Document (CE Models)

Available Models

With Manual Controller

120ASX-UPC1M

With Programmable Controller

120ASX-UPC1 120ASX-UPC12





17692 Fitch, Irvine, CA 92614 USA

Phone: +1 949.251.1800

Fax: +1 949.756.0756 Toll Free: 800.854.2433

E-mail: sales@pacificpower.com

www.pacificpower.com